
CONTENTS

Preface **xxi**

Chapter 1 Radio Propagation **1**

- 1.1 Introduction, 1
- 1.2 Loss in Free Space, 2
- 1.3 Atmospheric Effects on Propagation, 4
 - 1.3.1 Introduction, 4
 - 1.3.2 Refractive Effects on Curvature of Ray Beam, 4
 - 1.3.3 Refractivity Gradients, 8
- 1.4 Diffraction Effects—The Fresnel Zone Problem, 14
- 1.5 Ground Reflection, 18
- 1.6 Fading, 19
 - 1.6.1 Introduction, 19
 - 1.6.2 Multipath Fading, 19
 - 1.6.3 Power Fading, 20
 - 1.6.4 *K*-Factor Fading, 22
 - 1.6.5 Surface Duct Fading on Over-Water Paths, 23
- 1.7 From Another Perspective—A Discussion of Fading, 25
 - 1.7.1 Comparison of Some Common Fading Types, 25
 - 1.7.2 Blackout Fading, 28
- 1.8 Fade Depth and Fade Duration, 31
- 1.9 Penalty for Not Meeting Obstacle Clearance Criteria, 32
- 1.10 Attenuation Through Vegetation, 33

Chapter 2 Line-of-Sight Microwave Radiolinks **37**

- 2.1 Objective and Scope, 37
- 2.2 Initial Planning and Site Selection, 38
 - 2.2.1 Requirements and Requirements Analyses, 38
 - 2.2.2 Route Layout and Site Selection, 40

- 2.3 Path Profiles, 43
 - 2.3.1 Determination of Median Value for *K*-Factor, 46
- 2.4 Reflection Point, 48
- 2.5 Site Survey, 51
 - 2.5.1 Introduction, 51
 - 2.5.2 Information Listing, 51
 - 2.5.3 Notes on Site Visit, 53
- 2.6 Path Analysis, 54
 - 2.6.1 Objective and Scope, 54
 - 2.6.2 Unfaded Signal Level at the Receiver, 55
 - 2.6.3 Receiver Thermal Noise Threshold, 58
 - 2.6.4 Calculation of IF Bandwidth and Peak Frequency Deviation, 61
 - 2.6.5 Pre-emphasis/De-emphasis, 64
 - 2.6.6 Calculation of Median Carrier-to-Noise Ratio (Unfaded), 67
 - 2.6.7 Calculation of Antenna Gain, 69
- 2.7 Fading, Estimation of Fade Margin, and Mitigation of Fading Effects, 70
 - 2.7.1 Discussion of LOS Microwave Fading, 70
 - 2.7.2 Calculating Fade Margin, 71
 - 2.7.3 Notes on Path Fading Range Estimates, 81
 - 2.7.4 Diversity as a Means to Mitigate Fading, 82
- 2.8 Analysis of Noise on a FM Radiolink, 87
 - 2.8.1 Introduction, 87
 - 2.8.2 Sources of Noise in a Radiolink, 89
 - 2.8.3 FM Improvement Threshold, 90
 - 2.8.4 Noise in a Derived Voice Channel, 91
 - 2.8.5 Noise Power Ratio (NPR), 95
 - 2.8.6 Antenna Feeder Distortion, 103
 - 2.8.7 Total Noise in the Voice Channel, 107
 - 2.8.8 Signal-to-Noise Ratio for TV Video, 107
- 2.9 Path Analysis Worksheet and Example, 108
 - 2.9.1 Introduction, 108
 - 2.9.2 Sample Worksheet, 108
- 2.10 Frequency Assignment, Compatibility, and Frequency Plan, 113

2.10.1	Introduction,	113
2.10.2	Frequency Planning—Channel Arrangement,	113
2.10.3	Some Typical ITU-R Channel Arrangements,	118
2.10.4	Several FCC Frequency Plans,	126
Chapter 3	Digital Line-of-Sight Microwave Radiolinks	137
3.1	Introduction,	137
3.1.1	Energy per Bit per Noise Density Ratio, E_b/N_0 ,	138
3.2	Regulatory Issues,	139
3.3	Modulation Techniques, Spectral Efficiency, and Bandwidth,	142
3.3.1	Introduction,	142
3.3.2	Bit Packing,	142
3.3.3	Spectral Efficiency,	145
3.3.4	Power Amplifier Distortion,	147
3.4	Comparison of Several Types of Modulation,	148
3.4.1	Objective,	148
3.4.2	Definitions and Notation,	148
3.4.3	Modulation Format Comparison,	149
3.4.4	Notes on Implementation and BER Performance,	150
3.5	Some System Impairments Peculiar to Digital Operation,	154
3.5.1	Mitigation Techniques for Multipath Fading,	155
3.5.2	ITU-R Guidelines on Combating Propagation Effects,	157
3.6	Performance Requirements and Objectives for Digital Radiolinks,	159
3.6.1	Introduction,	159
3.6.2	Five Definitions,	159
3.6.3	Hypothetical Reference Digital Path (HRDP) for Radio-Relay Systems with a Capacity Above the Second Hierarchical Level,	159
3.6.4	Error Performance Objectives for Real Digital Radiolinks Forming Part of a High-Grade Circuit in an ISDN Network,	160
3.6.5	Error Performance Objectives of a 27,500-km Hypothetical Reference Path,	163
3.6.6	Jitter and Wander,	164

- 3.6.7 Error Performance from a Bellcore Perspective, 165
- 3.7 Application of High-Level *M*-QAM to High-Capacity SDH/SONET Formats, 165
- 3.8 Considerations of Fading on LOS Digital Microwave Systems, 166
 - 3.8.1 Introduction, 166
 - 3.8.2 Other Views of Calculations of Fade Margins on Digital LOS Microwave, 167
 - 3.8.3 Multipath Fading Calculations Based on TIA TSB 10-F, 168
 - 3.8.4 Simple Calculations of Path Dispersiveness, 173
- 3.9 Path Analyses or Link Budgets on Digital LOS Microwave Paths, 174

Chapter 4 Forward Error Correction and Advanced Digital Waveforms 179

- 4.1 Objective, 179
- 4.2 Forward Error Correction, 179
 - 4.2.1 Background and Objective, 179
 - 4.2.2 Basic Forward Error Correction, 181
 - 4.2.3 FEC Codes, 184
 - 4.2.4 Binary Convolutional Codes, 191
 - 4.2.5 Channel Performance of Uncoded and Coded Systems, 200
 - 4.2.6 Coding with Bursty Errors, 205
- 4.3 Advanced Signal Waveforms, 211
 - 4.3.1 Block-Coded Modulation (BCM), 211
 - 4.3.2 Trellis-Coded Modulation (TCM), 214
 - 4.3.3 Multilevel-Coded Modulation (MCLM), 215
 - 4.3.4 Partial Response with a Soft Decoder, 217

Chapter 5 Over-the-Horizon Radiolinks 223

- 5.1 Objectives and Scope, 223
- 5.2 Application, 223
- 5.3 Introduction to Tropospheric Scatter Propagation, 224
- 5.4 Tropospheric Scatter Link Design, 227
 - 5.4.1 Site Selection, Route Selection, Path Profile, and Field Survey, 227
 - 5.4.2 Link Performance Calculations, 228

- 5.5 Path Calculation/Link Analysis, 288
 - 5.5.1 Introduction, 288
 - 5.5.2 Path Intermodulation Noise—Analog Systems, 288
 - 5.5.3 Sample Link Analysis, 293
- 5.6 Threshold Extension, 295
- 5.7 Digital Transhorizon Radiolinks, 296
 - 5.7.1 Introduction, 296
 - 5.7.2 Digital Link Analysis, 296
 - 5.7.3 Dispersion, 298
 - 5.7.4 Some Methods of Overcoming the Effects of Dispersion, 299
 - 5.7.5 Some ITU-R Perspectives on Transhorizon Radio Systems, 301
- 5.8 Troposcatter Frequency Bands and the Sharing with Space Radio-Communication Systems, 304
 - 5.8.1 Frequency Bands Shared with Space Services (Space-to-Earth), 304

Chapter 6 Basic Principles of Satellite Communications 309

- 6.1 Introduction, Scope, and Applications, 309
- 6.2 Satellite Systems—An Introduction, 310
 - 6.2.1 Satellite Orbits, 310
 - 6.2.2 Elevation Angle, 312
 - 6.2.3 Determination of Range and Elevation Angle of a Geostationary Satellite, 313
- 6.3 Introduction to Link Analysis or Link Budget, 315
 - 6.3.1 Rationale, 315
 - 6.3.2 Frequency Bands Available for Satellite Communications, 315
 - 6.3.3 Free-Space Loss or Spreading Loss, 319
 - 6.3.4 Isotropic Receive Level—Simplified Model, 319
 - 6.3.5 Limitation of Flux Density on Earth's Surface, 320
 - 6.3.6 Thermal Noise Aspects of Low-Noise Systems, 322
 - 6.3.7 Calculation of C/N_0 , 325
 - 6.3.8 Gain-to-Noise Temperature Ratio, G/T , 327
 - 6.3.9 Calculation of C/N_0 Using the Link Budget, 336
 - 6.3.10 Calculation S/N , 341
- 6.4 Access Techniques, 347
 - 6.4.1 Introduction, 347

- 6.4.2 Frequency Division Multiple Access (FDMA), 349
- 6.4.3 Brief Overview of Time Division Multiple Access (TDMA), 356
- 6.5 INTELSAT Systems, 358
 - 6.5.1 Introduction, 358
 - 6.5.2 INTELSAT Type A Standard Earth Stations, 358
 - 6.5.3 INTELSAT Standard B Earth Stations, 364
 - 6.5.4 INTELSAT Standard C Earth Stations, 365
 - 6.5.5 INTELSAT Standard D Earth Stations, 365
 - 6.5.6 INTELSAT Standard E Earth Stations, 367
 - 6.5.7 INTELSAT Standard F Earth Stations, 368
 - 6.5.8 Basic INTELSAT Space Segment Data Common to All Families of Standard Earth Stations, 368
 - 6.5.9 Television Operation Over INTELSAT, 368
- 6.6 Domestic and Regional Satellite Systems, 376
 - 6.6.1 Introduction, 376
 - 6.6.2 Rationale, 377
 - 6.6.3 Approaches to Cost Reduction, 377
 - 6.6.4 A Typical Satellite Series that Can Provide Transponder Space for Enterprise Networks, 378

Chapter 7 Digital Communications by Satellite 385

- 7.1 Introduction, 385
- 7.2 Digital Operations of a Bent-Pipe Satellite System, 386
 - 7.2.1 General, 386
 - 7.2.2 Digital FDMA Operation, 386
 - 7.2.3 TDMA Operation on a Bent-Pipe Satellite, 398
- 7.3 Digital Speech Interpolation, 407
 - 7.3.1 Freeze-Out and Clipping, 408
 - 7.3.2 TASI-Based DSI, 409
 - 7.3.3 Speech Predictive Encoding DSI, 410
- 7.4 INTELSAT TDMA/DSI System, 411
 - 7.4.1 Overview, 411
 - 7.4.2 Frame, Multiframe, and Burst Format, 413
 - 7.4.3 Acquisition and Synchronization, 419
 - 7.4.4 Transponder Hopping, 419
 - 7.4.5 Digital Speech Interpolation Interface, 419

- 7.5 Processing Satellites, 420
 - 7.5.1 Primitive Processing Satellite, 421
 - 7.5.2 Switched-Satellite TDMA (SS/TDMA), 422
 - 7.5.3 IF Switching, 425
 - 7.5.4 Intersatellite Links, 426
- 7.6 Performance Considerations for Digital Satellite Communications, 429
 - 7.6.1 Hypothetical Reference Digital Path for Systems Using Digital Transmission in the Fixed-Satellite Service, 429
 - 7.6.2 BERs at the Output of a HRDP for Systems Using PCM Telephony, 430
 - 7.6.3 Allowable Error Performance for a HRDP in the Fixed-Satellite Service Operating Below 15 GHz When Forming Part of an International Connection in an ISDN, 430
 - 7.6.4 Allowable Error Performance for a HRDP Operating at or Above the Primary Rate (The Impact of ITU-T Rec. 5.826), 432
- 7.7 Link Budgets for Digital Satellites, 435
 - 7.7.1 Commentary, 435

Chapter 8 Very Small Aperture Terminals 443

- 8.1 Definitions of VSAT, 443
- 8.2 VSAT Network Applications, 443
 - 8.2.1 One-Way Applications, 444
 - 8.2.2 Two-Way Applications, 445
- 8.3 Technical Description of VSAT Networks and Their Operations, 446
 - 8.3.1 Introduction, 446
 - 8.3.2 A Link Budget for a Typical VSAT Operation at Ku-Band, 446
 - 8.3.3 Summary of VSAT RF Characteristics, 451
- 8.4 Access Techniques, 451
 - 8.4.1 Random Access, 453
 - 8.4.2 Demand-Assigned Multiple Access, 454
 - 8.4.3 Fixed-Assigned FDMA, 455
 - 8.4.4 Summary, 456
 - 8.4.5 Outbound TDM Channel, 456
- 8.5 A Modest VSAT Network in Support of Short Transaction Communications, 457

- 8.6 Interference Issues with VSATs, 461
- 8.7 Excess Attenuation Due to Rainfall, 464

Chapter 9 Radio System Design Above 10 GHz 467

- 9.1 The Problem—An Introduction, 467
- 9.2 The General Propagation Problem Above 10 GHz, 468
- 9.3 Excess Attenuation Due to Rainfall, 470
 - 9.3.1 Calculation of Excess Attenuation Due to Rainfall for LOS Microwave Paths, 473
- 9.4 Calculation of Excess Attenuation Due to Rainfall for Satellite Paths, 483
 - 9.4.1 Calculation Method, 483
 - 9.4.2 Rainfall Fade Rates, Depths, and Durations, 486
 - 9.4.3 Site or Path Diversity, 487
- 9.5 Excess Attenuation Due to Atmospheric Gases on Satellite Links, 488
 - 9.5.1 Example Calculation of Clear Air Attenuation—Hypothetical Location, 491
 - 9.5.2 Conversion of Relative Humidity to Water Vapor Density, 492
- 9.6 Attenuation Due to Clouds and Fog, 494
- 9.7 Calculation of Sky Noise Temperature as a Function of Attenuation, 496
- 9.8 The Sun as a Noise Generator, 497
- 9.9 Propagation Effects with a Low Elevation Angle, 499
- 9.10 Depolarization on Satellite Links, 499
- 9.11 Scintillation Fading on Satellite Links, 499
- 9.12 Trade-off Between Free-Space Loss and Antenna Gain, 500

Chapter 10 Mobile Communications: Cellular Radio and Personal Communication Services 507

- 10.1 Introduction, 507
 - 10.1.1 Background, 507
 - 10.1.2 Scope and Objective, 507
- 10.2 Some Basic Concepts of Cellular Radio, 508
 - 10.2.1 N-AMPS Increases Channel Capacity Threefold, 512
- 10.3 Radio Propagation in the Mobile Environment, 513
 - 10.3.1 The Propagation Problem, 513
 - 10.3.2 Several Propagation Models, 513

- 10.3.3 **Microcell Prediction Model According to Lee, 516**
- 10.4 **Impairments—Fading in the Mobile Environment, 519**
 - 10.4.1 **Introduction, 519**
 - 10.4.2 **Classification of Fading, 520**
 - 10.4.3 **Diversity—A Technique to Mitigate the Effects of Fading and Dispersion, 522**
 - 10.4.4 **Cellular Radio Path Calculations, 525**
- 10.5 **The Cellular Radio Bandwidth Dilemma, 525**
 - 10.5.1 **Background and Objectives, 525**
 - 10.5.2 **Bit Rate Reduction of the Digital Voice Channel, 526**
- 10.6 **Network Access Techniques, 526**
 - 10.6.1 **Introduction, 526**
 - 10.6.2 **Frequency Division Multiple Access (FDMA), 527**
 - 10.6.3 **Time Division Multiple Access (TDMA), 528**
 - 10.6.4 **Code Division Multiple Access (CDMA), 531**
- 10.7 **Frequency Reuse, 539**
- 10.8 **Paging Systems, 542**
 - 10.8.1 **What Are Paging Systems?, 542**
 - 10.8.2 **Radio-Frequency Bands for Pagers, 542**
 - 10.8.3 **Radio Propagation into Buildings, 542**
 - 10.8.4 **Techniques Available for Multiple Transmitter Zones, 542**
 - 10.8.5 **Paging Receivers, 543**
 - 10.8.6 **System Capacity, 544**
 - 10.8.7 **Codes and Formats for Paging Systems, 544**
 - 10.8.8 **Considerations for Selecting Codes and Formats, 544**
- 10.9 **Personal Communication Systems, 545**
 - 10.9.1 **Defining Personal Communications, 545**
 - 10.9.2 **Narrowband Microcell Propagation at PCS Distances, 546**
- 10.10 **Cordless Telephone Technology, 550**
 - 10.10.1 **Background, 550**
 - 10.10.2 **North American Cordless Telephones, 550**
 - 10.10.3 **European Cordless Telephones, 550**
- 10.11 **Wireless LANs, 553**

- 10.12 Future Public Land Mobile Telecommunication System (FPLMTS), 553
 - 10.12.1 Introduction, 553
 - 10.12.2 Traffic Estimates, 553
 - 10.12.3 Estimates of Spectrum Requirements, 556
 - 10.12.4 Sharing Considerations, 558
 - 10.12.5 Sharing Between FPLMTS and Other Services, 558
- 10.13 Mobile Satellite Communications, 559
 - 10.13.1 Background and Scope, 559
 - 10.13.2 Overview of Satellite Mobile Services, 559
 - 10.13.3 System Trends, 560
 - 10.13.4 IRIDIUM, 561

Chapter 11 High-Frequency (HF) Transmission Links, 577

- 11.1 General, 577
- 11.2 Applications of HF Radio Communication, 577
- 11.3 Typical HF Link Operation, Conceptual Introduction, 579
- 11.4 Basic HF Propagation, 579
 - 11.4.1 Introduction, 579
 - 11.4.2 Skywave Transmission, 581
- 11.5 Choice of Optimum Operating Frequency, 584
 - 11.5.1 Frequency Management, 591
- 11.6 Propagation Modes, 602
 - 11.6.1 Basic Groundwave Propagation, 602
 - 11.6.2 Skywave Propagation, 603
 - 11.6.3 Near-Vertical Incidence (NVI) Propagation, 604
 - 11.6.4 Reciprocal Reception, 608
- 11.7 HF Communication Impairments, 609
 - 11.7.1 Introduction, 609
 - 11.7.2 Fading, 609
 - 11.7.3 Effects of Impairments at the HF Receiver, 612
- 11.8 Mitigation of Propagation-Related Impairments, 615
- 11.9 HF Impairments—Noise in the Receiving System, 617
 - 11.9.1 Introduction, 617
 - 11.9.2 Interference, 617

- 11.9.3 Atmospheric Noise, 620
- 11.9.4 Man-Made Noise, 626
- 11.9.5 Receiver Thermal Noise, 629
- 11.10 Notes on HF Link Transmission Loss Calculations, 629
 - 11.10.1 Introduction, 629
 - 11.10.2 Transmission Loss Components, 629
 - 11.10.3 A Simplified Example of Transmission Loss Calculation, 638
 - 11.10.4 Groundwave Transmission Loss, 639
- 11.11 Link Analysis for Equipment Dimensioning, 644
 - 11.11.1 Introduction, 644
 - 11.11.2 Methodology, 645
- 11.12 Some Advanced Modulation and Coding Schemes, 647
 - 11.12.1 Two Approaches, 647
 - 11.12.2 Parallel Tone Operation, 647
 - 11.12.3 Serial Tone Operation, 649
- 11.13 Improved Lincompex for HF Radio Telephone Circuits, 654

Chapter 12 Meteor Burst Communication

661

- 12.1 Introduction, 661
- 12.2 Meteor Trails, 662
 - 12.2.1 General, 662
 - 12.2.2 Distribution of Meteors, 664
 - 12.2.3 Underdense Trails, 664
 - 12.2.4 Overdense Trails, 665
- 12.3 Typical Meteor Burst Terminals and Their Operation, 667
- 12.4 System Design Parameters, 669
 - 12.4.1 Introduction, 669
 - 12.4.2 Operating Frequency, 670
 - 12.4.3 Data Rate, 670
 - 12.4.4 Transmit Power, 670
 - 12.4.5 Antenna Gain, 670
 - 12.4.6 Receiver Threshold, 670
- 12.5 Prediction of MBC Link Performance, 671
 - 12.5.1 Introduction, 671
 - 12.5.2 Receiver Threshold, 671

- 12.5.3 Positions of Regions of Optimum Scatter, 672
- 12.5.4 Effective Length, Average Height, and Radius of Meteor Trails, 674
- 12.5.5 Ambipolar Diffusion Constant, 675
- 12.5.6 Received Power, 675
- 12.5.7 Meteor Rate, 678
- 12.5.8 Burst Time Duration, 679
- 12.5.9 Burst Rate Correction Factor, 682
- 12.5.10 Waiting Time Probability, 683
- 12.6 Design/Performance Prediction Procedure, 687
- 12.7 Notes on MBC Transmission Loss, 687
- 12.8 MBC Circuit Optimization, 689
- 12.9 Meteor Burst Networks, 690
- 12.10 Privacy and the Meteor Burst Footprint, 690

Chapter 13 Interference Issues in Radio Communications 695

- 13.1 Rationale, 695
- 13.2 Spurious Response Interference Windows at a Receiver, 696
- 13.3 Typical Interference Control for Line-of-Sight Microwave and Satellite Communication Facilities, 697
 - 13.3.1 Introduction, 697
 - 13.3.2 Conceptual Approach to Interference Determination, 698
 - 13.3.3 Applicable FCC Rule for Minimum Antenna Radiation Suppression, 703
 - 13.3.4 Coordination Contours, 705
 - 13.3.5 The FCC Rule—Calculation of Maximum Permissible Interference Power, 707
- 13.4 Victim Digital Systems, 710
- 13.5 Definition of C/I Ratio, 712
 - 13.5.1 Example C/I Calculations Based on Ref. 6, 713
 - 13.5.2 Example of Digital Interferer into Victim Digital System, 716
- 13.6 Obstructed Interfering Paths, 719
- 13.7 CCIR Approach to Digital Link Performance Under Interference Conditions, 720

13.7.1 Gaussian Interference Environment—
M-QAM Systems, 720

Chapter 14 Radio Terminal Design Considerations 727

- 14.1 Objective, 727
 - 14.1.1 The Generic Terminal, 727
- 14.2 Analog Line-of-Sight Radiolink Terminals and Repeaters, 728
 - 14.2.1 Basic Analog LOS Microwave Terminal, 728
- 14.3 Digital LOS Microwave Terminals, 731
 - 14.3.1 Gray or Reflected Binary Codes, 734
 - 14.3.2 The Antenna Subsystem for LOS Microwave Installations, 735
 - 14.3.3 Analog Radiolink Repeaters, 746
 - 14.3.4 Diversity Combiners, 747
 - 14.3.5 Hot-Standby Operation, 755
 - 14.3.6 Pilot Tones, 759
 - 14.3.7 Service Channels, 761
 - 14.3.8 Alarm and Supervisory Subsystems, 762
 - 14.3.9 Antenna Towers—General, 766
 - 14.3.10 Waveguide Pressurization, 771
- 14.4 Tropospheric Scatter and Diffraction Installations: Analog and Digital, 772
 - 14.4.1 Antennas, Transmission Lines, Duplexer, and Related Transmission Line Devices, 774
 - 14.4.2 Modulator-Exciter and Power Amplifier, 775
 - 14.4.3 FM Receiver Group, 776
 - 14.4.4 Diversity Operation, 776
 - 14.4.5 Isolation, 777
- 14.5 Satellite Communications, Terminal Segment, 778
 - 14.5.1 Functional Operation of a “Standard” Earth Station, 778
 - 14.5.2 The Antenna Subsystem, 783
 - 14.5.3 Very Small Aperture Terminals (VSATs), 793
- 14.6 Cellular and PCS Installations: Analog and Digital, 794
 - 14.6.1 Introduction, 794
 - 14.6.2 Base Station or Cell Design Concepts, 795
 - 14.6.3 The MTSO or MSC, 797
 - 14.6.4 Personal Communication Services, 799

14.7	HF Terminals and Antennas,	800
14.7.1	Introduction,	800
14.7.2	Composition of Basic HF Equipment,	801
14.7.3	Basic Single-Sideband (SSB) Operation,	802
14.7.4	SSB System Considerations,	803
14.7.5	Linear Power Amplifiers,	804
14.7.6	HF Configuration Notes ,	806
14.7.7	HF Antennas,	806
14.8	Meteor Burst Installations,	814
14.8.1	Yagi Antennas,	815
Appendix 1	Availability of a Line-of-Sight Microwave Link	821
A1.1	Introduction,	821
A1.2	Contributors to Unavailability,	822
A1.3	Availability Requirements,	823
A1.4	Calculation of Availability of LOS Radiolinks in Tandem,	823
A1.4.1	Discussion of Partition of Unavailability,	823
A1.4.2	Propagation Availability,	825
A1.5	Improving Availability,	825
A1.6	Application to Other Radio Media,	826
Appendix 2	Reference Fields and Theoretical References; Converting RF Field Strength to Power	827
A2.1	Reference Fields—Theoretical References,	827
A2.2	Conversion of Radio-Frequency (RF) Field Strength to Power,	829
Appendix 3	Glossary of Acronyms and Abbreviations	831
Index		843