

CONTENTS

	PAGE
Introduction,	I
CHAPTER I.	
The Diesel Cycle,	14
CHAPTER II.	
Elementary Thermodynamics of the Diesel Cycle,	23
CHAPTER III.	
General Description of a Marine Diesel Engine,	36
CHAPTER IV.	
Liquid Fuels,	52
CHAPTER V.	
Combustion and Thermal Efficiencies,	87
CHAPTER VI.	
Fuel Combustion Adjustments,	101
CHAPTER VII.	
Bedplates, Columns and Cylinders,	125
CHAPTER VIII.	
Fuel Injection Measuring Pumps,	180
CHAPTER IX.	
Fuel Injection Valves,	233
CHAPTER X.	
Air Inlet and Exhaust Valves and Operating Mechanism,	284
CHAPTER XI.	
Exhaust Gas Pipes,	327
CHAPTER XII.	
Pistons and Piston Rings,	340

	PAGE
CHAPTER XIII.	
Piston Cooling and Cooling Medium Conveying Mechanism,	391
CHAPTER XIV.	
Starting and Reversing Diesel Engines,	423
CHAPTER XV.	
Air Compressors,	492
CHAPTER XVI.	
Scavenging and Supercharging,	540
CHAPTER XVII.	
Lubricating Oils,	577
CHAPTER XVIII.	
Lubrication of Bearings and Cylinders,	598
CHAPTER XIX.	
Bearing Adjustment and Operation,	620
CHAPTER XX.	
✓ Crankshafts, Propeller Shafts and Thrust Bearings,	647
CHAPTER XXI.	
Pressure Indicators and Indicator Diagrams,	681
CHAPTER XXII.	
Materials of Construction : Corrosion,	721
CHAPTER XXIII.	
Preparing an Engine for Sea,	735
CHAPTER XXIV.	
General Operation and Watch-keeping,	752
CHAPTER XXV.	
Useful Workshop Hints,	804
APPENDIX.	
Conversion Tables and Useful Constants,	823
<hr/>	
INDEX TO TEXT,	835